

Dräger Parat® C Smoke hood



ST-1587-2008

ST-9709-2007



1 Take the hood into both hands.

ST-9724-2007



2 Push out the filter ...

ST-9725-2007



3 ... using both thumbs.

ST-9713-2007



4 Open the elastic neck seal using both hands.

ST-9712-2007



5 First insert your chin into the hood resting it inside the inner mask.

ST-9727-2076



6 Pull the hood over your head. Make sure that your nose and chin sit comfortably in the inner mask and that all your hair is tucked into the hood.

ST-9717-2007



7 Tighten the strap ...

ST-9721-2007



8 ... until the inner mask lies firmly over your mouth and nose.

Dräger Parat® C Smoke hood



ST-1596-2005

Twin Pack



ST-9689-2007

1 Wall box containing two hoods.



ST-9700-2007

2 Pull firm on the cover of the wall box to detach the security seal. Remove the hood.



ST-9701-2007

3 Hold the red pull cords in one hand and use your other hand to pull the hood until both filter seals are opened.



ST-9706-2007

4 The filter openings must be free to ensure unrestricted breathing.

Soft Pack



ST-9730-2007

1 Handy travel case.



ST-9731-2007

2 Open the zipper of the Soft Pack and remove the hood.



ST-9734-2007

3 Hold the red pull cords in one hand and use your other hand to pull the hood until both filter seals are opened.



ST-9735-2007

4 The filter openings must be free to ensure unrestricted breathing.

Carton



ST-278-2002

1 Environmentally-friendly cardboard box.



ST-9736-2007

2 Open the box and pull out the inner carton. Remove the hood from the inner carton.



ST-9743-2007

3 Hold the red pull cords in one hand and use your other hand to pull the hood until both filter seals are opened.



ST-9745-2007

4 The filter openings must be free to ensure unrestricted breathing.

Traveller Pack



ST-9747-2007

1 Robust plastic casing for rough environments.



ST-9749-2007

2 Remove the metal clamp to open the box and remove the hood.



ST-9755-2007

3 Hold the red pull cords in one hand and use your other hand to pull the hood until both filter seals are opened.



ST-9759-2007

4 The filter openings must be free to ensure unrestricted breathing.