

Dräger REGARD 4-20 mA Control card

A single channel control card with local display, 3 gas alarm levels, optional fault, repeat 4 to 20 mA and a remote reset input.



D-15086-2009

The Dräger REGARD 4-20 mA single channel control card is a universal control card for all analogue gas detectors. Each card is fully configurable to match the parameters of an associated gas detector. The control card is fully independent and standalone, or can be addressed to interface with other system cards.

FEATURES AND BENEFITS

- Measuring for Tox, Ex or O₂-Suitable for all 2/3 wire transmitters
- Fully configurable
- Simple operation
- Continuous display
- Password protected



ST-331-2004

Dräger REGARD 4-20 mA

TECHNICAL DATA

Control card	Local alphanumeric display Front panel push buttons Front panel LED's
Inputs	2/3 wire 4-20 mA transmitters Remote reset
Outputs	A1, A 2 and F/A 3 alarm relays Repeat 4-20 mA
Power Supply	24 V DC, 125 mA
Measuring Ranges	0-1 to 0-9999
Units of Measure	vol%, ppm, LEL and many others
Gas Names	H ₂ S, CL ₂ , O ₂ , CH ₄ and many others
Approvals	Tested to EN 50270 for EMC directive ATEX II (2)G Acc. to Directive 94/9/EC DMT
Safety Integrity Level	SIL2 certified by exida (IEC 61508)

ORDER INFORMATION

Dräger REGARD 4-20 mA	42 05 701
Dräger REGARD 4-20 mA (ATEX)	46 06 706
Dräger REGARD 4-20 mA (DMT)	42 06 307

HEADQUARTERS

Dräger Safety AG & Co. KGaA
Revalstrasse 1
23560 Lübeck, Germany

www.draeger.com

SYSTEM CENTERS**P. R. CHINA**

Beijing Fortune Draeger Safety
Equipment Co., Ltd.
A22 Yu An Rd, B Area,
Tianzhu Airport Industrial Zone,
Shunyi District, Beijing 101300
Tel +86 10 80 49 80 00
Fax +86 10 80 49 80 05

GERMANY

Dräger Safety AG & Co. KGaA
Revalstrasse 1
23560 Lübeck
Tel +49 451 882-2794
Fax +49 451 882-4991

FRANCE

Dräger Safety France SAS
3c route de la Fédération, BP 80141
67025 Strasbourg Cedex 1
Tel +33 3 88 40 59 29
Fax +33 3 88 40 76 67

SINGAPORE

Draeger Safety Asia Pte Ltd
67 Ayer Rajah Crescent #06-03
Singapore 139950
Tel +65 68 72 92 88
Fax +65 65 12 19 08

UNITED KINGDOM

Draeger Safety UK Ltd.
Blyth Riverside Business Park
Blyth, Northumberland NE24 4RG
Tel +44 1670 352 891
Fax +44 1670 544 475

USA

Draeger Safety, Inc.
505 Julie Rivers, Suite 150
Sugar Land, TX 77478
Tel +1 281 498 1082
Fax +1 281 498 5190